

How to ... Get a PLDS File

Finding PLDS Number via Manager Software

1. Open IP Office Manager
2. Select 'Licence' in options on left
3. This will show PLDS Host ID and current license Version/Release

